

## User manual for integral blinds

Congratulations on their new blind product. A window with integrated blind is a product with many benefits that you will enjoy for many years. This user guide provides answers to the most common questions regarding the use of blinds. By following these simple guidelines, it is ensured that the product does not suffer any damage.

### In general

When a blind is integrated in a pane, the blind shield will cause the temperature to rise further between the glass layers. Idealcombi therefore, as a general rule, uses tempered glass in these solutions, to avoid tension. Using anything other than tempered glass increases the risk of tension breakage. In these cases, it is important to ensure a uniform shielding of the entire area of the pane, and thereby achieve an even temperature over the glass, as an unevenly heated pane can cause thermal stresses.

Always have a specialist connect the blind window, including accessories, and only use original Screenline accessories. Defects due to incorrect connection are not covered by Idealcombi's warranty.

Vertically fitted blinds may only be operated when hanging vertically and not when the window is opened. Tilting, horizontally swinging frames (eg top guide) must max. tilt 15 degrees from the vertical when the blind is in the lowered position.

Shielding	Functions	Userguidance
Slat (Venetian)	Raise, lower & tilt are most common. If the function is limited to tilt, it is often a consequence of the width and height ratio of the pane, or the total area of the pane.	Never drive the slats all the way up for a long time, as packed slats can stick together at high temperatures.
Pleated curtain	Only raise & lower	
Rollerblinds	Only raise & lower	

### Operation

#### Use of blinds with drawstring:

Always be located right next to the place where the blind is to be operated. Avoid to jerk the string, use calm, smooth movements.

#### Use of blinds with Motor:

The motor is dimensioned for the individual blind model, and cannot suffer from overload, with a correctly dimensioned power supply, as well as a motor control designed for requirements. There are many options for control. Therefore, describe in detail how your blind features can and should be activated.

### Cleaning

Externally mounted blind parts are gently cleaned with a slightly damp, clean cloth. Let the blind's shielding material be packed together by glass cleaning.

### Maintenance

The product does not require user maintenance.

### Safety

During manual operation, the magnets are designed with an automatic fall protection, but due to the risk of suffocation, children must not come into contact with the cord loop.